

## **Quick Start Guide**

## **Energy Communication Unit (ECU) for Smart Phone**

Version 1.0 10/16

APsystems

600 Ericksen Ave. NE Ste 200

Seattle, WA 98110

TEL: 844-666-7035 EMAIL: info@APsystems.com

WEB: www.APsystems.com

© All Rights Reserved

**NOTE:** The ECU uses two functionally separate protocols: TCP I.P. and Power Line Communications (PLC). Do not plug ECU into a surge protector or power strip, only in a wall outlet for PLC. This Quick Start is not for a direct connect to a laptop/desktop.




Minimum requirements: Standard AC Electrical Outlet

Smart Phone


Router

**Additional Requirements** if connecting to the Energy Monitoring Analysis (EMA) web site (see EMA quick start):



**STEP 1.** Using your smart phone, bring up your "Settings" screen and select Wi-Fi.

## Android



## Apple



Figure 2 & 3

STEP 2. Locate your ECU, it will be identified by ECU-WIFI and the last four digits of the UID located on the side of the ECU. (e.g. ECU-WIFI\_2482) Once located, connect to the ECU by selecting it.




Figure 4

**STEP 3.** Select Connect.






Figure 5


**STEP 4.** Bring up your web browser and type in 172.30.1.1




**STEP 5.** Once the "APsystems" home page comes up, select "Administration" from the drop down menu.



STEP 6. In the "Administration" page, select "WLAN" from the more menu.



**STEP 7.** Select your network from the "Available Networks", type in the password and select "Connect".



**STEP 8.** Once connected, select "LWA" to turn on the security feature.




Figure 10

safe type

STEP 9. From the "Safe Type" drop down, select "WEP"




Figure 11

STEP 10. Type in a five digit password, e.g. 12345 and select "Save"




Figure 12

STEP 11. The ECU is now wireless.




Figure 13